

Do Not Use Harsh Cleaners

Concentration of Hydrogen ions compared to distilled water.

Line Cleaners on the pH Scale

10,000,000	pH=0	PureVac (0.5 – 1.5)
1,000,000	pH=1	BM 6000 (1.05)
100,000	pH=2	PureGreen24 (2.0) AquaFx (2.5)
10,000	pH=3	E20 (3.5 -4.5)
1,000	pH=4	
100	pH=5	
10	pH=6	Denta-Zyme (6.0 – 8.5)
1	pH=7	CleanLINZ (6.6 – 7.4) PowerLINZ (7.0)
1/10	pH=8	Neutravac (7.0 – 8.0) Em Power (7.5 – 8.5)
1/100	pH=9	Bio Vac (8.5) CleanStream (8.5 – 10.9)
1/1,000	pH=10	Gobble (9.0) PureVac Sc (9.4)
1/10,000	pH=11	MicroVac (9.0 – 10.0) VacAttak (10.5-11.5)
1/100,000	pH=12	Evaculine (11.5) Vacusol Ultra (12.4)
1/1,000,000	pH=13	
1/10,000,000	pH=14	

Preferred

Preferred

